

Assembling GSORIG Outriggers to GSSI Scaffolding

The outriggers and steel bolts are placed OUTSIDE the leg of the GSSI.

Do not try to insert the steel bolts into the holes of the GSSI support leg.

Attach the clamp to the bolt, and securely tighten it.

Repeat this process on all four support legs.

⚠ WARNING

Be certain that all Outriggers are securely tightened.

Double check that each bolt has been secured before using the scaffold.

