



READ ALL INSTRUCTIONS AND WARNINGS BEFORE USING THIS PRODUCT.

Every effort has been made to ensure the accuracy of this manual. These instructions are not meant to cover every possible condition and situation that may occur. We reserve the right to change this product at any time without prior notice.

IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE! FOR CONSUMER USE ONLY - NOT FOR PROFESSIONAL USE.

HAVE QUESTIONS OR PROBLEMS? DO NOT RETURN THIS PRODUCT TO THE RETAILER -CONTACT CUSTOMER SERVICE.

If you experience a problem or need parts for this product, visit our website <u>http://www.buffalotools.com</u> or call our customer help line at **1-888-287-6981**, **Monday-Friday**, **8 AM - 4 PM Central Time**.

KEEP THIS MANUAL, SALES RECEIPT & APPLICABLE WARRANTY FOR FUTURE REFERENCE.

A WARNING

Keep your work area clean and well lit. Cluttered and dark work areas may cause accidents or injury. Keep bystanders, children and visitors away while operating.

A WARNING

Use common sense while operating. Do not use this if you are feeling tired or are under the influence of alcohol or drugs; Wearing loose clothing or jewelry. Keep long hair pulled back and away from moving parts; Overreaching or have improper footing.

A WARNING

This is not a toy. Do not sit, stand, or lay on top of the cart. Do not push the cart with people or pets on top of it. Keep away from children.



Install 4 casters on the underside of the deck, using lock and flat washer and hex bolt. Place 2 swivel casters on one end, and 2 locking casters on the other end. Slide the handrail tube into the deck at the swivel caster end. If the handrail is installed on the end with the fixed casters, the cart will not turn correctly.