CHICKEN FEATHER PLUCKER

INSTRUCTIONS Items needed for use • Water & Water Hose • Boiling Pot • Electric Power



Before you turn on the plucker, connect the water hose and connect the power. Make sure any electric outlet is safely away from water.



Prepare a separate pot of scalding hot water. Insert the chicken, and spin the bird for about 30 seconds. The hot water will help loosen the feathers.



Turn on the power to the feather plucker. Water will spray everywhere. Make sure any electric outlet is safely away from spraying water.



Insert the chicken into the tub. The bird will tumble around like the inside of a clothes dryer.



As the chicken tumbles, the water and rubber fingers help remove feathers in about 60 seconds.



Water washes the feathers into the feather chute. (Place a bucket to the side for excess water and feathers.)



Once the bird is fully de-feathered, you can turn the power off.

Wait until the tub stops rotating before vou remove the chicken.

Allow the excess feathers to wash down into the tub and off the fingers. Remove excess feathers from the tub.

Now you can turn the power on and begin de-feathering additional birds.

SCAN TO WATCH INSTRUCTIONAL VIDEO

