Model # IW12BX 12V DC Electric Impact Wrench INSTRUCTION MANUAL



Thank you for purchasing this IW12BX Electric Impact Wrench. This manual provides important information on its proper operation and maintenance. Every effort has been made to ensure the accuracy of this manual. We reserve the right to change this product at any time without prior notice.

Before use, read carefully and understand all warnings, cautions, instructions and labels. Failure to do so could result in serious personal injury, property damage or even death.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

STOP!

DO NOT RETURN THIS TOOL TO THE RETAILER.

Questions? Problems? CONTACT BUFFALO TOOLS.

If you experience a problem or need parts for this product, visit our website <u>http://www.buffalotools.com</u> or call our customer help line at 1-888-287-6981, Monday-Friday, 8 AM - 4 PM Central Time. A copy of the sales receipt is required.

080310



FEATURES:

- 150 Ft. lbs. of Torque
- 11 Foot Cord Plugs Into Cigarette Lighter
- 2 Foot Adapter Cable For Hook-Up Directly To Car Battery
 4 Piece, 1/2" Square Drive Impact Sockets: 11/16", 3/4", 13/16", and 7/8"
- Forward & Reverse Modes
- Lockable Trigger
- LED Light For Night Use
- 2 12A-250V Fuses

SPECIFICATIONS:

| Rated Current | <15 AMP |
|-----------------------------------|---------|
| | |

- Rated Voltage 120V/60Hz
- Blows Per Minute 30-40 BPM 1/2" Square
- Drive Size • Maximum Torque
 - 150 Ft. lbs.

FOR CONSUMER USE ONLY – NOT FOR PROFESSIONAL USE

GENERAL SAFETY RULES FOR ALL ELECTRIC POWER TOOLS

WARNING: When using this tool, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment and vehicles. The warnings, cautions and instructions in this manual cannot cover all situations and conditions. The user must exercise common sense.

READ ALL INSTRUCTIONS BEFORE USING THIS TOOL!

- 1) Keep work area clean. Cluttered areas invite injuries. If emergency dictates use of this tool on the road, keep work area as clear of clutter as possible. Park vehicle on firm, level ground away from traffic.
- 2) **Observe work area conditions**. If forced to use this tool in wet or damp conditions, extreme care must be observed as serious personal injury may result if tool is exposed to moisture.
- 3) Keep children away. Children must be kept at a safe distance when using this and other tools. Failure to do so may result in serious injury or death.
- 4) **Store idle equipment**. When not in use, store the impact wrench in its carrying case. Store case in a dry location to reduce chance of rust. Lock up tools and keep out of reach of children.
- 5) Use the right tool for the job. Use this tool only as intended. Do not modify this tool and do not use for a purpose for which it was not intended.
- 6) **Dress properly**. Secure loose clothing, jewelry or long hair to prevent them from getting caught in moving parts of the tool or vehicle, especially if using the battery adapter cable.
- 7) Use hearing and eye protection. Always use ANSI approved hearing and eye protection.
- 8) Maintain tools with care. Clean, properly functioning tools ensure better and safer performance. Inspect the cord periodically and if damaged, have it repaired by an authorized technician. Failure to do so may result in serious personal injury and possible damage to equipment or vehicle.
- 9) Disconnect power. Unplug tool when not in use.
- 10) Avoid unintentional starting. Be sure the trigger is locked when not in use and before plugging in. Do not carry any tool with your finger on the trigger, whether it is plugged in or not.
- 11) Stay alert. Use common sense when using this and other tools. Do not use any tool when you are tired or under the influence of drugs or alcohol. Failure to do so may result in damage to equipment, vehicle, personal injury or death.
- 12) **Replacement parts and accessories**. When servicing, use only identical replacement parts. Use of any other parts will void the warranty. Only use accessories intended for use with this tool. Contact Buffalo Tools at 888-287-6981 if you need a replacement part.
- 13) People with pacemakers should consult their physician(s) before using this product. Electromagnetic fields in close proximity to a heart pacemaker could cause interference to or failure of the pacemaker.
- 14) Use this tool with both hands. This tool requires the use of both hands when operating. This helps maintain tool stability and keeps hands away from the working area of the tool.
- 15) **This unit should only be powered by 12 Volt DC systems**. Do not alter the power cord for use in AC sockets. Doing so is both dangerous and voids the warranty.

PACKAGE CONTENTS

- 12V DC Electric Impact Wrench
- 4 Impact Sockets, Sizes 3/4", 11/16", 7/8", and 13/16"
- 2-Foot Adapter Cable For Automobile Battery Hook-Up
- 2 Spare 12A-250V Fuses
- High Impact Plastic Carrying Case (Not Shown)



- 1. Anvil
- 2. LED Light
- **3**. Trigger Locking Switch
- 4. Forward and Reverse Trigger
- 5. Pistol Grip
- 6. Sockets: 11/16", 3/4", 13/16", 7/8"
- 7. 2 Spare 12A-250V Fuses

- 8. 12V Plug-In
- 9. Negative Terminal Clamp (Black Handle)
- **10.** Positive Terminal Clamp (Red Handle)
- 11. Automobile Battery Adapter


OPERATING INSTRUCTIONS

WARNING! Gasoline engines create carbon monoxide, an odorless, colorless, tasteless gas that causes headaches, nausea, dizziness and even death if exposure is prolonged. The engine does not have to be running to use this impact wrench. If forced to run the engine, do so in a well-ventilated area.


NOTE: The motor in this wrench spins until it reaches maximum speed, then the internal clutch automatically engages and the nut is loosened or tightened. THIS IS NORMAL AND DOES NOT INDICATE A PROBLEM.

Prior to using this impact wrench, be sure your vehicle or wheel is secured. If wheel is still on the vehicle, make certain the vehicle is parked on firm, level ground, that it is in "Park" and that the Emergency Brake is engaged. Use wheel chocks on the other wheels if available or a large rock, large piece of wood – anything to prevent inadvertent movement of the vehicle.


This tool operates on 12V DC, such as that found in a standard automobile battery. Do not attempt to use this tool with any other voltage. Do not alter the power cord in any way. Doing so is both dangerous and voids the warranty.




As shown in Figure 1, you may connect this impact wrench directly into the 12V receptacle (A), the cigarette lighter in your vehicle, or you may use the Battery Adapter Cable (B) and use the vehicle battery itself.





To use the Battery Adapter Cable, simply insert the 12V plug-in (C) into the adapter. (Figure 2) Then connect the Red clamp (D) to the Red Positive terminal (F) of a 12V automobile battery. The Positive terminal is marked with a +.



Connect the Black clamp (E) to a clean, grounded part of the vehicle such as the engine block or frame member (G). (Figure 3)







Select the appropriate size socket (H) to fit the wheel lug nut. Attach the socket to the impact wrench by pressing it on to the Anvil (I). For best results, use only the sockets that came with this wrench. Be sure the spring-loaded pin (J) on the Anvil lines up with the matching hole on the socket securing the socket firmly to the impact wrench. (Figure 4)

NOTE: The motor in this wrench spins until it reaches maximum speed, then the internal clutch automatically engages and the nut is loosened or tightened. THIS IS NORMAL AND DOES NOT INDICATE A PROBLEM.


Use the impact wrench to loosen the lug nuts on the wheel while the vehicle is still firmly on the ground, otherwise the wheel will spin. Once the lug nuts are loosened, use the vehicle jack to lift the vehicle off the ground. **Refer to the vehicle owner's manual for instructions on using the jack**. When the vehicle is off the ground, finish removing the lug nuts by hand or with a socket wrench.

This impact wrench is reversible. To tighten, set the directional lever toward the "R" symbol on the right side of the handle. To loosen, switch the lever to the "L" symbol (L) on the left side of the handle. If the Trigger Locking Switch (K) is set in the middle, the unit will not turn in either direction. (Figure 5)

Replace the wheel on the vehicle, aligning the wheel studs with the boltholes in the wheel. Be sure the air valve faces out. Install the wheel lug nuts, following the vehicle manufacturer's recommendations on tightening. To avoid cross-threading the lug nuts, thread the nuts on by hand first, before using the impact wrench. Do not use the impact wrench to tighten the lug nuts as you may over-tighten them.

Once the wheel is securely in place, check to make sure there are no tools or other equipment beneath the vehicle before lowering it to the ground. Do not let the power cords come into contact with any vehicle wiring. Additionally, disconnect the clamps as soon as work is finished and put the wrench in its case. Then check to make sure there are not tools or equipment on the engine deck before closing the hood.


NOTE: This impact wrench is equipped with an automatic LED light (M) for use in low light conditions. (Figure 6)



MAINTENANCE

When not in use, store your impact wrench and its accessories in its case. Store the case in a secure, dry place. Protect it from water, moisture, oil, fuel, grease or other foreign materials, which may damage the case, moving parts, or its internal electrical components.

The 12V plug-in assembly has a fuse that will eventually need replacing. Warning: Use only 12A-250V fuses (N) of the same style as shown in the figure at left. To replace the fuse, remove the cap at the end of the plug-in and replace the fuse making sure to replace the pieces in the same order as shown. (Figure 7)



PARTS LIST

| Part No. | Description | Part No. | Description |
|----------|-----------------------|----------|---------------|
| 1 | Bearing | 21 | Bolt |
| 2 | Anvil Bearing | 22 | Cable Block |
| 3 | Radial Bearing | 23 | Cable Bushing |
| 4 | Anvil | 24 | 12-V Plug-In |
| 5 | Oil Bearing | 25 | Left Housing |
| 6 | Ratchet Wheel Base | 26 | Trigger |
| 7 | Wheel | 27 | LED |
| 8 | Wheel Tray | 28 | Bolt |
| 9 | Pull Spring | 29 | Wheel |
| 10 | Wheel Brace | 30 | Pull Spring |
| 11 | Ratchet Wheel Bearing | 31 | Bolt |
| 12 | Pedestal Bearing | 32 | Bolt |
| 13 | Gear | 33 | Pawl |
| 14 | Gear Shaft | 34 | Rod |
| 15 | Drive Wheel | 35 | 7/8" Socket |
| 16 | Motor Gear Wheel | 36 | 13/16" Socket |
| 17 | Gear Box Lid | 37 | 3/4" Socket |
| 18 | Bolt | 38 | 11/16" Socket |
| 19 | Right Housing | 39 | Bolt |
| 20 | Motor | | |

NOTES: