

Item # PS07215

18 Volt Cordless Drill Operating Instructions



READ ALL INSTRUCTIONS AND WARNINGS BEFORE USING THIS PRODUCT.

This manual provides important information on proper operation & maintenance. Every effort has been made to ensure the accuracy of this manual. These instructions are not meant to cover every possible condition and situation that may occur. We reserve the right to change this product at any time without prior notice.

IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE THIS PRODUCT!

HAVE QUESTIONS OR PROBLEMS? DO NOT RETURN THIS PRODUCT TO THE RETAILER - CONTACT CUSTOMER SERVICE.

If you experience a problem or need parts for this product, visit our website <http://www.buffalotools.com> or call our customer help line at 1-636-532-9888, Monday-Friday, 8 AM - 4 PM Central Time. A copy of the sales receipt is required.

FOR CONSUMER USE ONLY – NOT FOR PROFESSIONAL USE.

KEEP THIS MANUAL, SALES RECEIPT & APPLICABLE WARRANTY FOR FUTURE REFERENCE.

GENERAL SAFETY RULES FOR ALL POWER TOOLS

WARNING

READ AND UNDERSTAND ALL INSTRUCTIONS. Failure to follow all instructions listed below may result in electric shock, fire and/or serious personal injury.

RECOGNIZE SAFETY SYMBOLS, WORDS AND LABELS

What You Need to Know About Safety Instructions

Warning and Important Safety Instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. Common sense, caution and care must be exercised when operating or cleaning tools and equipment.

Always contact your dealer, distributor, service agent or manufacturer about problems or conditions you do not understand.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.



NOTE provides additional information that is useful for proper use and maintenance for this tool. If a NOTE is indicated make sure it is fully understood.

IMPORTANT SAFETY INSTRUCTIONS

WORK AREA

WARNING

Keep your work area clean and well lit. Cluttered work benches and dark work areas may cause accidents or injury.

Do not operate power tools in explosive areas, such as in the presence of flammable liquids, gases or dust. Power tools can create sparks which may ignite the dust or fumes.

Keep bystanders, children and visitors away while operating a power tool. Distractions can cause you to lose control.

TOOL USE & CARE

CAUTION

Use clamps or other practical ways to secure and support the workpiece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.

Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.

Do not use the tool if the power switch does not turn it “ON” or “OFF”. Any tool that cannot be controlled with the switch is dangerous and must be repaired.

Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.

DANGER

People with pacemakers or other electronic devices should consult with a physician before operating this product. Interruption or failure of the pacemaker could occur when electrical equipment is operated within close proximity of electrical devices.

WARNING

Inhaling dust created as a result of construction projects could be hazardous to your health.

These chemicals could be, but are not limited to: lead from lead based paints, crystalline silica from bricks or cement, arsenic, and chromium from chemically treated-lumber.

To reduce your risk of exposure to harmful materials: always wear a dust mask that is designed to filter out hazardous microscopic contaminants, always work in a well ventilated area, and wear other approved safety equipment.

WARNING

Wash hands after handling the tool.

WARNING

All work areas should be clean and well lit. Accidents are more likely to occur in poorly lit and cluttered areas.

WARNING

Keep children, and other distractions at a distance while operating power tools.

⚠ WARNING

Use common sense while operating this tool.

Do not use this tool if you are:

- Feeling tired or are under the influence of alcohol or drugs.
- Wearing loose clothing or jewelry. Keep long hair pulled back and away from moving parts.
- Overreaching or have improper footing. Handling the tool in this way could cause serious injury.

When using this power tool always:

- Wear the proper safety equipment, such as safety goggles, dust masks, non-skid shoes, etc.

⚠ CAUTION

Follow these steps to maintain safe working conditions and good working condition of power tools. Improper care can result in electric shock or serious injury.

- Secure and support the work piece using clamps. **Do not use your hands to hold the piece in place.**
- **Use the correct tool for the job.** Using the correct tool is safer and faster.
- **Make sure the power switch is in good working order.** If the power switch no longer turns the tool “ON” or “OFF”, discontinue use, and have the tool replaced or repaired.
- **Keep out of reach of children**, or any untrained person. Store tools in a safe and dry place.
- **Keep tools clean, and cutting tools sharp.** Maintaining tools with proper care will increase the life of the power tool, and reduce the risk of injury.
- **Check to be sure all moving parts are free from binding and are properly aligned.**
- Use only accessories that are recommended by the manufacturer for your tool model.
- **Hold the tool by the insulated grip when using in an area where contact with a “live” wire is a possibility.**

NOTE

Only qualified repair personnel must perform tool service. Service or maintenance performed by unqualified personnel could result in a risk of injury.

⚠ WARNING

Safety glasses and ear protection must be worn during operation.

LED LIGHT

The LED light is integrated into the drill. When the unit is fully charged and the trigger is pressed, the LED light will turn on. When the trigger is released, the LED light will turn off.



BUILT-IN LIQUID FILLED LEVEL

The Liquid Filled Level enables perfectly perpendicular drilling.



IMPORTANT SAFETY INSTRUCTIONS

⚠ WARNING

Before using you need to become familiar with the operation of the tool. If you are unsure about the operation of the tool, or have any questions about the proper use of the tool, call Customer Service at 1-636-532-9888.

Follow these instructions for safe handling of the tool:



- Always secure and support the work piece using clamps. **Do not use your hands to hold the piece in place.**
- **Do not use solvents containing carbon tetrachloride, ammonia or acetone to clean the tool.** Never use gasoline, paint thinner, or other caustic chemicals that can damage the plastic parts of the tool.
- **Always use the appropriate safety gear when operating this tool.** Including but not limited to, goggles, dust mask or respirator. Always work in a well-ventilated area to reduce your exposure to harmful chemicals and dust particles.

FEATURES


- 550 RPM
- Forward / Reverse
- Keyless Chuck 3/8"
- 16 Torque Settings
- Integrated LED Light
- Built-In Liquid Filled Level
- Blow Mold Carry Case

PACKAGE CONTENTS

- Drill
- Storage Case (A)
- 18V NiCd Battery (B)
- Charging Dock (C)
- Power Supply Adaptor (D)
- 6 Drill Bits (E)
- 6 Screwdriver Bit (F)
- 1 Extension Bit (G)



Power Supply Adapter
120V AC 60 Hz
24V DC, 0.4A



Charging Dock





Figure 3
(3) Battery (Press Lever on both sides to remove)

COMPONENTS

Observe the locations and functions of the various components and controls of this tool.



- 1) Chuck
- 2) Chuck Sleeve
- 3) Battery
- 4) Trigger
- 5) Forward/Reverse
- 6) LED Light
Turns On Automatically
When Trigger is Pressed
- 7) Level
- 8) Magnet




Figure 2

INSERTING DRILL BITS

WARNING

Make sure the power is turned off before assembly, adjustments, or adding/removing accessories.

WARNING

Using the power of the drill to adjust the diameter of the chuck could cause serious injury.

Loosen the chuck sleeve by rotating counter-clockwise, then open the chuck to the approximate diameter of the drill bit. For small drill bits, insert the bit into the opening of the drill flute. For larger bits, push the bit in as far as it will go. To tighten the chuck sleeve, rotate clockwise until the bit is held firmly in the chuck.

DRILL OPERATION

NOTE

Unpack product from package and review contents. Keep all packaging until product has been reviewed.

NOTE

Damage to the tool can occur if the forward / reverse button is moved while the chuck is turning.

The forward / reverse lever changes the direction of the drill rotation. With the drill pointed towards the work area, move the lever to the right side (Figure 2) for forward (clockwise) rotation, and the left side for reverse (counterclockwise) rotation.

Pulling the trigger starts the drill. Increase drill speed by pulling back on the trigger. To control the torque at which the drill will rotate, turn the Adjustable Sleeve. There are 16 settings.

DRILLING TIPS

CAUTION

Applying too much pressure can result in damage to the drill bit, which could result in serious injury.

CAUTION

Be prepared and braced for the twisting action of the drill.

CAUTION

Wear safety eyewear and dust filters or respirators while using the tool.

CAUTION

The motor may overheat if run for long periods of time. If the motor begins to show signs of overheating, turn the drill "Off" and allow the motor to cool before continuing.

Before beginning, check to make sure the bit is held securely in the chuck, and the forward / reverse button is set for clockwise rotation

Using a center punch, locate the center of the hole to be drilled. Place the tip of the drill on the spot to be drilled, and press the trigger to start the motor. Continue to apply an even pressure on the work to keep the bit cutting into the surface.

If the drill becomes jammed, release the trigger and stop drilling to investigate the cause.

When drilling in wood, frequently remove the bit from the work to clear away wood chips that can build up on the bit. Use a backing block to keep wood from splitting. Be sure the backing block is held securely in place with clamps. If you are not using a backing block, stop drilling when the bit breaks through, and complete the hole from the opposite side.

BATTERY CHARGING

This battery capacity is 800mAh.

Remove the battery from the drill by pressing the side tabs of the battery (Figure 3). Insert Battery into the Charging Dock, and allow to charge for 3-5 hours. Do not leave the battery in Charging Dock over 5 hours

The battery is not fully charged during shipment. If using for the first time, you should charge the battery before use.

Plug Charging Dock into power outlet. The Red Light will turn on. Insert battery into Charging Dock and the Red and Green Lights will turn on. It takes 3 - 5 hours to fully charge a battery. Do not leave the battery in Charging Dock over 5 hours. The Red and Green Lights will not turn off once charging is complete.

The battery will not fully charge during the first operation. Allow several cycles for fully charged battery.

MAINTENANCE

WARNING

Disconnect the battery supply before cleaning. Wear safety eyewear before cleaning. Use compressed dry air to blow off dust and debris. Use a soft bristle brush if compressed air is not available.

CAUTION

Applying excessive force to the tool can overload the motor, decrease the life and increase the wear on the tool.

CAUTION

Some chemicals damage the product. Do not use harsh chemicals such as gasoline, carbon tetrachloride, paint thinner, etc.

Use only mild soap and a slightly damp cloth to clean the tool.

ACCESSORIES

Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool may become hazardous when used on another tool.

201803