## **Step-By-Step Quick Start Guide To Using Your Generator**

# **Remove Generator From Package**

Add Oil

Oil Type: SAE10W-30 Oil (Must add BEFORE first use) Oil Capacity: 20 fluid oz

Because this generator includes Low Oil Shut Off, the generator will not start with low oil. Start out with 18.6 oz, then fill until almost overflowing.)

- Add Fuel If using Gasoline, add Unleaded gasoline only octane rating of 87 or higher. Maximum Capacity: 3.6 Gallon gasoline fuel tank
  - If using Propane, connect Regulator Hose to Propane Tank and the LP Gas Inlet on Generator.

### **Start The Generator**

- Use the generator OUTDOORS in a WELL VENTILATED AREA.
- DO NOT CONNECT electrical devices until AFTER the generator is started.
- Turn Engine Power Switch to ON A. If using GASOLINE, Turn FUEL PETCOCK to ON (Figure A) B. If using PROPANE, turn FUEL PETCOCK to OFF first, then connect regulator hose and turn Tank Valve to ON (Figure B)
- Adjust the CHOKE to CLOSED TO START position (Figure C)
- Start the generator manually with the Recoil (Pull) Start.
- Once the engine has started, GRADUALLY move the choke lever to the "OPEN TO RUN" position until the engine levels off. Then let the engine run approximately 5 minutes BEFORE adding appliances or tools.
- You can now connect electrical devices.





Figure A) Fuel Petcock



LP Gas Inlet (Figure B)





**Choke Position (Figure C)** 





4,000 Surge / 3,500 Running Watts

#### **POWERED BY UNLEADED GASOLINE OR PROPANE FUEL**

#### **GENERATOR SPECIFICATIONS:**

- 7.0 HP Engine, 4 Stroke OHV
- · Recoil Start
- 3.6 Gallon Fuel Tank
- · Low Oil Shut Off
- AVR Automatic Voltage Regulation
- UL Listed Electrical Components
- · Engine Shut Off Switch
- Circuit Breaker & Power Outlets
- 1 12V D/C Outlet
- 4 120V A/C Outlets
- 1 120V RV Outlet
- Complies with EPA emissions
- Run time = 10 hours @ 50% load
- Decibel Rating < 69 db @ 0% load
- · Warranty: 2 YEAR Limited Emissions
- · Warranty: 1 YEAR Limited
- \* SURGE WATTS / RUNNING WATTS MAY BE REDUCED BY 10% WHEN USING PROPANE FUEL VS USING GASOLINE.
- If you are using a generator 3,000 ft. above sea level, the generator may not function properly because of air flow getting through the carburetor.
- · High Altitude Use: This generator is not recommended for high altitude use 3,000 ft. above sea level.

**OIL IS NOT INCLUDED WITH THIS GENERATOR. IT IS SOLD SEPARATELY.** 

Read and understand instruction manual before using generator.





**Need Help? Call Customer Service!** 


Monday-Friday 8:00-4:00 Central Time





4,000 Surge / 3,500 Running Watts





DO NOT CONNECT electrical devices until AFTER the generator is started.



IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE THIS PRODUCT!

Always follow Warning labels placed on the generator, and read and follow all Warning labels included inside the Product Manual.

WARNING: NEVER use a generator inside a home or a garage, EVEN IF the doors and windows are open.

ONLY USE OUTSIDE and far way from windows, doors and vents leading into an enclosed area.

Using a generator indoors can kill you in minutes. The generator produces an exhaust that contains carbon monoxide. This is a poison you cannot see or smell.

Do not attach a chain or rope to secure the generator to a post as this can be difficult to remove in the event of an emergency.



### **TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436**

**Need Help? Call Customer Service!** 

Monday-Friday 8:00-4:00 Central Time

SPORTSMAN.